

## INSTALLATION INSTRUCTIONS

**STEP 1:** If possible, remove lens from nurse call light.

**STEP 2:** Place the mounting bracket **(A)** directly below the nurse call light, to desired height.  
Mount using preferred screw type.

**STEP 3:** Thread the nipple **(B)** into the mounting bracket **(A)**.

**STEP 4:** Slide the plastic washer **(C)**, glass shade **(D)**, and trim piece **(E)** onto the nipple **(B)**.

**STEP 5:** Secure and tighten with finial **(F)**.

## CLEANING

To clean, wipe the fixture with a soft cloth.

Clean glass with a mild soap.

Do not use abrasive materials such as scouring pads, powders, or steel wool.

